

2.6.1 Microswitch control

Type 30	Code 200.9686.1050.0	Microswitch is operated when the spool is in pos. 1	
Type 32	Code 200.9686.1060.0	Microswitch is operated when the spool is in pos. 2	
Type 34	Code 200.9686.1064.0	Microswitch is operated when the spool is in pos. 1 and 2	

* The microswitch is supplied only on customer's request.

2.7 Spool charts

Spool scheme	Spool features	Type		
	4 way - 3 position A/B closed E open by pass	A		3 way - 3 position B closed E open by pass G
	4 way - 3 position A/B-E closed	B		4 way - 3 position with regenerative spool in 1 st position R**
	4 way - 3 position A/B to tank in neutral E open by pass	C		3 way - 3 position A closed E open by pass S
				4 way - 4 position 4 th floating position Z

** : special body required